



Boost adjustment dial



Boost sensing port from engine



Electrical connection

